The following catalog has gaps in its page numbers, or doesn't have any numbers. We have chosen to leave the page numbering in the order that Acrobat assigns it.



PARTS CATALOG

FOR




ELECTRIC GENERATING PLANTS





ONAN 1400 73RD AVENUE N.E. • MINNEAPOLIS, MINNESOTA 55432



INSTRUCTIONS FOR ORDERING REPAIR PARTS

ONAN PARTS


All parts in this list are **Onon** parts. For **Onon** parts or service, contact the dealer from who you purchased this equipment or your nearest authorized service station. To avoid errors or delay in filling your order, please refer to the **Onon** nameplate located on the upper right side of the flywheel housing and give the complete:

INTERNATIONAL HARVESTER PARTS

All International Harvester parts must be ordered from the International Harvester Company, Chicago, Illinois or the nearest International Harvester Construction Equipment distributor or dealer.

Refer to the International Harvester nameplate located on the right side of the flywheel housing as viewed facing the radiator end.

When ordering parts or requesting service information supply all information stated on engine nameplate and engine serial number which is stamped on front of cylinder block directly below right hand cylinder head.



	NAL FII HARVES	TER CO
	HICAGO, ILLINOIS	
MODEL		Service of makes and a service of the
SERIAL NO.		
MAX. IDLE SPEED	FULL LOAD SPEED	
DO	NOT OVERLOAD)



This catalog applies to the standard ONAN KB Series plants as listed below. Powered by an International Harvester UV401 engine (see International Harvesters Manual). Engine parts modified or added by ONAN will be in this list and have ONAN part numbers. These supersede similar parts listed in the International Harvester manual. ONAN parts are arranged in groups of related items and are identified by a reference. All parts illustrations are typical. Unless otherwise mentioned, parts are interchangeable. Right and left plant sides are determined by facing the front end of the engine.

PLANT DATA TABLE

MODEL & SPEC NO. *		ELECTRICAL DATA					
		WATTS**	VOLTS	CYCLES	PHASE	WIRE	
HOUSED	UNHOUSED						
50KB-3R/	50K 8-3R8/	55,000	120/240	60	I	3	
50KB-4R/	50KB-4R8/	55,000	120/208	60	3	4	
50KB-4XR/	50KB-4XR8/	55,000	277/480	60	3	4	
50KB-5DR/ £	50KB-5DR8/ £	55,000	120/240	60	3	4	
50KB-6R/	50KB-6R8/	55,000	480	60	3	3	
50KB-9R/	50KB-9R8/	55,000	600	60	3	3	
60KB-3R/	60KB-3R8/	65,000	120/240	60	l	3	
60KB-4R/	60KB-4R8/	65,000	120/208	60	3	4	
60KB-4XR/	60KB-4XR8/	65,000	277/480	60	3	4	
60KB-5DR/ <u>£</u>	60KB-5DR/£	65,000	120/240	60	3	4	
60KB-6R/	60KB-6R8/	65,000	480	60	3	3	
60KB-9R/	60KB-9R8/	65,000	600	60	3	3	

- * The Specification Letter advances (A to B, B to C, etc.) with manufacturing changes.
- ** Maximum rating is shown. Continuous rating also appears on nameplate.
- 6 This is a delta-wound 240-volt model with one phase center-tapped. A limited amount of 1-phase, 120/240-volt power can be utilized together with 3-phase power as long as no terminal current exceeds the rated nameplate current.

REPLACEMENT ENGINE

100P440


Engine, Replacement (Replaces #100P264, and #100P310) - International Harvester Co. Model UV-401, Spec 0-26E.

General Description:

Includes - Complete Cylinder Block, Oil Pan, Water Pump, Oil Filter, Governor, Exhaust Manifolds, and Engine Mounts.

Excludes - Carburetor, Fuel Pump, Air Cleaner, Fuel Filter, Starter & Solenoid, Charge Generator, Regulator & More Harness, Ignition Coil, Distributor, Spark Plug & Leads, Oil Pressure, Water Temperature Gauge Senders, Oil Pressure Switch, High Water Temperature Cut Off Switch, Anti-Dieseling Control, Radiator, Fan Blades & Belt, Exhaust Header, Muffler and Exhaust Tube.






REF.	PART NO.	QTY. USED	PART DESCRIPTION
Ι,	166-282	ı	*Distributor Assembly (Delco Remy #1110625)
2	166-280	ı	Coil, Ignition - 12 Volt
3	166-281	1	Resistor, Ignition Coil
4	133B158	1	Shield, Ignition Coil Heat.
5	167-127	8	Plug, Spark
6	314P156	8	Suppressor, Spark Plug
7	160A558	10	Nipple, Rubber (9) Distributor, (1) Ignition Coil
8	336A332	•	Lead, Ignition Coil to Resistor - 5-1/4" Long
9	312A58	ı	Condenser, Ignition Coil - 0.1 Mfd.
10	CABLE.	BATTERY	
	416A77	(28 '' Long
	416A21	1	20-1/2 "Long

REF.	PART NO.	QT' USE				
11	167.A1316	I Lead, Distributor to Suppressor-7-1/4" Lo				
12	314P6	ŧ	Suppressor, Distributor			
13	167 A 13 12	1	Lead, Suppressor to Ignition Coil			
14	LEAD, SPA	RK PLU	G			
	167A1332	2	Cylinder No. 1 & 7			
	167 A 1333	2	Cylinder No. 2 & 4			
	167A1334	F	Cylinder No. 3			
	167 A 1335	T.	Cylinder No. 5			
	167 A 336	2	Cylinder No. 6 & B			
15	166-318	ı	Cap, Distributor			
16	166-319	1	Rotor, Distributor			
17	166-320	F	Condenser, Distributor			
18	166-321	l	Point Set, Breaker			

^{* -} For components not listed, contact your nearest Delco Remy dealer or Delco Remy Div. of General Motors Corp., Anderson, Indiana 46011.







REF.		QTY.	PART	
<u>NO.</u>	NO.	USED	DESCRIPTION	
1	140C524	1	Cleaner, Air	
_	ADAPTER,	_		
2	140A525	1	Prior to Spec C and Begin Spec K	
2A	140A549	Ł	Spec C through j	
3	102A34		Gasket, Oil Drain Adapter	
4	102A33	i	Adapter, Oil Drain	
5	502-133	1	Efbow, Oil Drain - 90°	
6	505-100	2	Nipple, Oil Drain - 1/2"	
7	504P11	1	Valve, Shut-Off - Oil Drain	
В	503-197	ŀ	Clamp, Oil Drain Hose	
9	503-348	1	Hose, Oil Drain	
10	193A108	1	Sender, Oil Pressure Gauge	
11	193A104	!	Sender, Water Temp, Gauge	
12	309A178	l	Switch, Water Temp. Cut-Off	
13	504-85	I	Valve, Shut-Off - Carb. Inlet - Begin Spec M	
14	309B64	I	Switch, Oil Pressure	
15	505-59	ı	Tee, Pipe (1/8") Oil Pressure Switch and Oil Gauge Sender	
16	505-104	ı	Mounting Nipple, Close (1/8"x 3/4")	
			Oil Pressure Tee to Block	
17	1400518	ļ	Cleaner, Crankcase Breatner	
18	505-369	i	Coupling, Reducer (1/2" to 1/4") Breather Cleaner to Mounting Nipple	
19	505-99	1 -	Nipple, Close (1/4" x 7/8") Breather Cleaner to Cylinder	
			Head Cover Mounting	
20	123A604	I	Valve, Metering - Breather System - Prior to Spec C	
2 I	123 B62 I	ŧ	Line, Breather - Metering Valve to Intake Manifold -	
			Prior to Spec C	
22	502-31	1	Connector, Inverted Male -	
			Breather Line to Intake Manifold - Prior to Spec C	
23	502-39	1	Elbow, Inverted Male - Breather	
23	302-37	•	Line to Metering Valve ~ Prior	
24	141C636	1	to Spec C Carburetor Assembly - (Order	
	141K872		Component parts by description	
	741111		for Carburetor Model 28ADA10C from Zenith Carburetor Div. of Bendix Aviation Corp., Detroit, Michigan)	
25	307 B259	i	Solenoid and Lead Assembly, Anti-Dieseling	
26	145A124	1	Link, Solenoid	
27	145A186	1	Bracket, Solenoid Mounting	
28	150A302	1	Bushing, Throttle Spring Link to Ball Joint	
29	145A118	1	Link, Throttle Spring	
30	145A158	1	Spring, Throttle	
31	150A96	1	Stud, Throttle Spring Adjusting	
3.3	1454187	t	Bracket Throttle Spring	

Bracket, Throttle Spring

REF	. PART	QTY.	PART
NO.	NO.	USED	DESCRIPTION
		3	
33 34	332-614		onnector Wire
24	BODY ASSE		
	145B188		rior to Spec H
	145B328		ec H through L
25	145 B4 10		egin Spec M
35	150A638	3 Jo	oint, Ball - (1) Solenoid Link,
27	1454100		(2) Governor Control Stud
37	145A 189	l G	asket, Carburetor to Solenoid
30	1454105		Mounting Bracket
38	145A1B5	2 G:	asket, Throttle Body -(1) Upper,
30	E20 A 457	4 6.	(I) Lower
39	520A457	4 St	ud, Carburetor & Throttle Body
	CTUD COU		Mounting (5/16 x 3-1/8)
41	STUD, GOV		
	520A537		ior to Spec H - 1/4 x 9-3/8"
	520A629		ec H_through L = 1/4 x 9-7/8"
	520A517		agin Spec M - 1/4 x 7"
42	141A372		nob, Choke - Carburetor
43	149C730		ımp Assembly, Fuel
44	149A736		asket, Fuel Pump Mounting
	ELBOW, INV	/ERTED MA	LE
45	502-4	l Fu	iel Pump Outlet
45A	502-4	I Ca	arburetor Inlet - Prior to SpecM
46	159C685		ne, Fuel - Pump to Carburetor
17	151B184	I Ga	isket, Governor Flange
18	505-10		pple, Half - 1/4 x 👫 -
			Breather Hose Adapter -
			Begin Spec C
19	503-131	2 CI	amp, Breather Hose - Begin
			Spec C
0	503-119	l Ho	se. Breather - Begin Spec C
1	309A132	l Ca	ım, Micro Switch - Begin Spec F
52	516-86		n, Roll - 1/8 " x 3/4 " -
			Begin Spec F
53	309P133	I Ac	tuator, Micro Switch -
			Begin Spec F
54	309A155	I Sw	itch, Micro - Begin Spec F
5	309A131		acket, Micro Switch Mounting -
			Begin Spec F
6	123A904		ame Arrestor Assy Spec H
			through J
57	123A960		ankcase Vent-Begin Spec K
	193 190R91	j ģ Fi	Iter Assembly, Oil - Includes
			Element (Not Illustrated)
	193 187 R9 I		ement, Oil Filter
	.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		(Not Illustrated)
	GD422C7545		vernor Assembly - Prior to
	0042007545		Spec D (Not Illustrated)
	GD427C7145		vernor Assembly - Spec D
	CD42/C/143	•	through G (Not Illustrated)
	347003R91		vernor Assembly - Spec H
	34/003 171		
			through L (Novi #4050078)
	151-271		Not Hlustrated)
	151-371		vernor Assembly - Begin Spec
	141 (40		1 (Pierce) (Not Illustrated)
	141-640		pair Kit, Carburetor
	141-641	I Ga	sket Kit, Carburetor

^{🛊 -} Part number is International, order direct from nearest dealer.




145A187

32

^{† -} Part number is Hoof, order direct from Hoof Products Co., Chicago, III.


Order parts or components for this governor (International #678045C91) from the International Harvester Co.,
 401 North Michigan Ave., Chicago, Illinois 60611.



REF. NO.	PART NO.	QTY. USED	PART Description	REI	-	QTY	
1	* CARBURE	TOR - GA	S-GASOLINE FUEL	27	145A205		Link, Solenoid to Choke
	148C371	1	Prior to Spec E (Ensign #9235)	28	145A195	1 (Gasket - Carburetor Air Inlet
	148C431	1	Begin Spec E (Ensign	1			or Choke
			#CCA200A116)	30	145A124		Link, Solenoid
2	503-107	4	Clamp, Hose	31	145C203	1	Bracket, Choke Solenoid
3	503-355	2	Hose - 1-1/4 1.D. x 3" Long	32	153-110	1	Choke, Manual
4	148A381	ł	Tube, Fuel Line - Regulator	33	145A213	1	Extension, Choke Arm
			to Carburetor	34	145A165	1	Stop, Choke Wire
5	148C365	l	Bracket, Regulator Mounting	35	308A150	1	Bracket, Switch Mounting
6	403 A 53 3	2	Spacer, Regulator Mounting	36	308P88	ļ	Switch, Choke (Gas or Gasoline)
			Bracket	37	153 A 27 4	1	Bracket, Choke Wire
7	148A310	I	*Regulator (Ensign	38	518B176	1	Clip, Choke Wire
			#RVE200A104-2)	39	153B292	1	Adapter Assembly, Choke
8	149A768	I	Line, Fuel Pump to	40	153A293	1	Shaft, Choke
			Carburetor	41	153A281	1	Plate, Choke
9	148C383	1	Shield Assembly, Heat	42	153 A49	1	Cover Assembly, Choke
10	148A107	l	Vent Assembly, Gas Regulator				(12 Volt)
П	130B451	I	Line, Oil Cooler to Cylinder	43	153A295	I	Bracket, Choke Lock
			Block	44	232A979	1	Spring, Choke Lock
12	153A275	t	Bracket, Choke	45	153A213	1	Choke, Automatic
13		SEMBLY, 7	THROTTLE	46	153A294	I	Rod, Choke
	145A 188	1	Prior to Spec H	47	518-5	2	Clip, Choke Rod End
	145B328	I	Spec H through K	48	153A283	1	Arm, Choke Over-Ride
14	150A63B	As Req.	-	49	153 A282		Arm, Choke
17	145A158	2	Spring, Throttle	50	148A430	ı	Counterweight, Choke Shaft
18	150A96	2	Stud, Throttle Spring	51	308A6B		Switch, Choke
			Adjusting	72	502-42	I	Elbow, Inverted Male -
19	145A187	l	Bracket, Throttle Spring	- [Carb. Inlet
20	145A118	1	Link, Throttle Spring	73	309A132	1	Cam, Micro Switch - Begin
21	145A189	1	Gasket, Carburetor Solenoid	[Spec F`
			Mounting Bracket	74	516-86	I	Pin, Roll - 1/8" x 3/4" - Cam -
22	145C202	l	Bracket, Solenoid Mounting				Begin Spec F
23	307 B259	t	Solenoid & Lead Assembly, Anti-Dieseling	75	309P133	1	Actuator, Micro Switch - Begin Spec F
24	150A302	1	Bushing, Throttle Spring Link	76	309A155	1	Switch - Micro - Begin Spec F
			to Ball Joint	77	309A131	1	Bracket, Micro Switch Mounting -
26	145A 194	1	Bracket, Choke Spring				Begin Spec F

^{* -} For components contact your nearest Ensign Carburetor dealer or Ensign Carburetor Div. of American Bosch, 930 North York Road, Room 206, Hinsdale, Illinois.





SPECIAL FUEL SYSTEM GROUP (Gas Only and LPG Only) -OPTIONAL



NO.	NO.	USED	DESCRIPTION
Ì	148P592	•	*Carburetor - Begin Spec K (Impco #200)
IA	*CARBURE	TOR - NAT	TURAL GAS FUEL
	148C372	1	Prior to Spec E (Ensign #9263)
	148C433	1	Spec E through J (Ensign #200A120)
ΙB	*CARBURE	TOR - LPC	G FUEL
	148C372	F	Prior to Spec C (Ensign #9263)
	148C424	ŀ	Spec C and D (Ensign #9496)
	148C434	ı	Spec E through K (Ensign #9505)
2	503-107	4	Clamp, Hose - Natural Gas Fuel Plants - Prior to Spec K
3	503-355	2	Hose - I-1/4 I.D. x 3" Lg. Natural Gas Fuel Plants - Prior to Spec K
4	148A382	1	Tube, Fuel Line - Regulator to Carburetor - Prior to Spec K
5	148C365	1	Bracket, Regulator Mounting - Natural Gas Fuel Plants
6	SPACER	REGILL AT	OR MOUNTING BRACKET
·	403A533	2	Prior to Spec H
	403 A85 I	2	Begin Spec H
7	148A310	ī	Regulator, Gas - Natural Gas
			Fuel Plants - Prior to Spec K
9	148C383	L	Shield Assembly, Heat -
			Natural Gas Fuel Plants -
			Prior to Spec K
10	148A107	1	Vent Assembly, Gas Regulator -
			Prior to Spec L
11	130 B45 I	ı	Line, Oil Cooler to Cylinder Block - Prior to Spec K
12	STUD, TH	ROTTLE	5
	520A629	I I	Prior to Spec M
13	520A517	EMBLY 1	Begin Spec M THROTTLE
13		ENDLI, I	Prior to Spec H
	145A188 145B328	1	Spec H through L
	145B410	i	Begin Spec M
14	150A638	As Req.	Joint, Ball
15	153 A85	1	Rod Assembly, Choke - LPG
			Plants Prior to Spec E
16	ELBOW, V LPG PLAI		WITCH LINE TO CARBURETOR -
	502-2	!	Prior to Spec C
	502-41	l	Spec C through G
17	145A158	l	Spring, Throttle - LPG Plants Spec C through K and Natural
			Gas Plants Begin Spec E
i B	150A96	I	Stud, Throttle Spring Adjusting LPG Spec C through K and Natural Gas Plants Begin
			Spec E
19	145A187	1	Bracket, Throttle Spring - LPG Plants Spec C through K
20	145.4118	l	Link, Throttle Spring - LPG Plants Spec C through K
21	145A (89	I	Gasket, Carburetor to Solenoid Mounting Bracket - LPG Plants
22	145A186	1	Spec C through K Bracket, Solenoid Mtg L.PG Plants Spec C through K


• •	-	For components contact your nearest Impco deafer or
		Impco Division, 16916 Gridley Place, Cerritos,
		California 90701.

For components contact your nearest Ensign Carburetor dealer or Ensign Carburetor Div. of American Bosch, 930 North York Road, Room 206, Hinsdale, Illinois.



REF	. PART	QT'	
NO.	NO.	USE	D DESCRIPTION
23	307B259	1	Solenoid & Lead Assembly, Anti-
			Dieseling - LPG Plants Spec C
			through K - Natural Gas Plants
			Prior to Spec E
24	150A302	J	Bushing, Throttle Spring Link to
			Ball Joint - LPG Plants
			Spec C through K
25	145C193		Bracket, Choke Sol Natural Gas
	1130173		Plants Prior to Spec E
28	145A195	1	Gasket - Carburetor Air Inlet or
20	1-4514175	·	Choke - Natural Gas Fuel Plants
29	153 B302	ı i	Choke Assembly, Air - Natural
47	133 0302	•	Gas Plants - Spec E through J
20	LAEA 19A	1	Link, Solenoid - LPG Fuel Plants
30	145A 24	'	- to Spec L
21	1/AL 1/E ==	THERMAI	- to spec L
31		THERMAL	Natural Gas Plants
	148-601	,	LPG Fuel Flants
	148 A636		
32	145P358	1	Adapter, Carburetor - Begin
			Spec K
33	148P620	ŀ	Collar, Shaft - Spec K only
34	145A185	2	Gasket, Throttle Body - Begin
			Spec K
35	307 P3 12	l	Valve, Solenoid (12 V) - LPG
			Plants Begin Spec L
36	505-129	1	Bushing, Reducer (1 x 3/4) -
			Thermal Valve Outlet
37	505-102	2	Nipple $(3/4 \times 1-3/8'')$ - Solenoid
			Valve Inlet & Outlet - LPG
			Plants Begin Spec L
52	148A368	;	 Regulator, LPG - LPG Plants
			(Ensign #RDB220A2)
53	148A367	1	Switch, Vacuum - Regulator -
			LPG Plants - Prior to Spec H
54	148C366	1	Bracket, Regulator - LPG Plants
55	148C369	1	Brace, Regulator Mounting -
7.5	, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		LPG Plants
56	110A300	3	Spacer, Regulator to Bracket
50	110/1500	3	Mounting - LPG Plants
57	503-350	ł	Hose, Fuel - 3" Lg LPG
37	303-330	•	Plants
FO	502.251	1	Hose, Fuel - B"Lg LPG
58	503-351	'	Plants
	503-189	4	Clamp, Fuel Hose -LPG Plants
59		1	Line, Fuel - LPG Plants
60	148A385	4	Clamp, Water Hose - LPG
61	503A49	4	Plants
40	502 252		Hose, Water Inlet - 20" Lg
62	503-352	1	
	4 45.00	COUNTY CON	LPG Plants
63			TCH - LPG PLANTS
	148A414	!	Prior to Spec C
	148A378	1	Spec C through G
65	502-2	1	Elbow, Vacuum Line to Vacuum
			Switch - LPG Plants - Prior
			to Spec H
66	131A122	I	Line, Water Outlet - LPG
			Plants
67	336A1093	I	Lead, Solenoid to Vacuum
			Switch - LPG Plants -
			Prior to Spec H
68	338B224	1	Harness, Wiring - LPG Plants
•			- Prior to Spec H

REF.	PART NO.	QTY. USED	PART DESCRIPTIONS	REF NO.	PART NO.	USED	
69	503-353	f	Hose, Water Outlet - 2" Lg LPG Plants	75	309P133	ł	Actuator, Micro Switch - Spec F through K
70	502-227	1	Connector, Water Outlet Hose-	76	309A155	1	Switch, Micro - Spec F through K
			LPG Plants	77	309A131	ţ	Bracket, Micro Switch Mounting
7 1	130B450	I	Bracket, Water Line - LPG Plants				- Spec F through K
73	309 A 132	1	Cam, Micro Switch - Spec F through K	78	140P851	ı	Cleaner, Air - Gas only Plants - Begin Spec K
74	516-86	ì	Pin, Roll - 1/8"x 3/4" - Cam - Spec F through K	79	140-871	l	Element, Air Cleaner Gas only Plants - Begin Spec K







REF.	PART NO.	QTY. USED	PART DESCRIPTION
1	148P598)	**Carburetor, Gas (Mixer)
	, 10. 570	4	(Impco #200)
2	145P396	ŧ	Adapter, Carburetor
3	503-550	1	Hose, Adapter
4	503-354	2	Clamp, Hose
5	*	1	Gasket, Carburetor Adapter
6	505-102	Ŧ	Nipple, Gas Regulator
			(3/4 × I-3/8")
7	505-129	-1	Bushing, Reducer (1 x 3/4") - Gas-Gasotine only
8	148P601	1	**Regulator, Gas - Gas-Gasoline
ь	1701001	Ţ	only (Impco #T-30)
9	505-356	F	Elbow, Reducer (1 x 3/4")
			LPG-Gasoline only
10	131B192	1	Line, Water - LPG-Gasoline
			only
11	307 P268	ŀ	Valve, Solenoid - LPG-Gasoline
10			only
12	148-631	ı	Bracket, Converter - LPG-
13	148€625	1	Gasoline only **Converter - LPG-Gasoline only
13	1406023	1	(Impco MdI, EB)
14	503-382	2	Clamp, Hose - LPG-Gasoline
	505 501	_	only
15	503-189	4	Clamp, Hose - LPG-Gasoline
			only
16	502-227	ţ	Connector - LPG-Gasoline only
17	505-107	ı	Nipple (1 x 2") ≟ LPG-Gasoline
18	505-71	2	only
10	303-71	2	Nipple, Half (3/4 x I-1/4") - LPG-Gasoline only

NO. 19 20	NO. 505-132	USED 3	
	305-132		E16 min 10/4/// 1 DO O
20		3	Elbow (3/4") - LPG-Gasoline
20	505-21	1	only
	303-21	,	Bushing, Reducer (3/4 x 1/2") - LPG-Gasoline only
21	505-135	2	Nipple, Half (3/8 x I-1/4") -
	303-133	•	LPG-Gasoline only
22	505-119	2	Elbow, Street (3/8") - LPG-
	303 117	-	Gasoline only
23		As Req.	Hose (17" of Bulk Hose #503-386)
			- LPG-Gasoline only
24		As Reg.	Hose (8-1/2" of Bulk Hose
			#503-386) - LPG-Gasoline only
25		As Reg.	Hose (11" of Bulk Hose #503-249)
			- LPG-Gasoline only
26	140P851	ı	Cleaner, Air
<u> 2</u> 7	140-871	İ	Element, Air Cleaner
28	502-42	İ	Elbow, Inverted Male -
			Carb. Inlet - Prior to Spec M
			- Gas-Gasoline only
29	504-85	l l	Valve, Shut-Off - Carb. Inlet -
			Begin Spec M + Gas-Gasoline
			only
30	BODY ASS	EMBLY, TH	IROTTLE - Gas-Gasoline Only
	145B32B	1	Spec L Only
	145B410	1	Begin Spec M
3 1	STUD, TH	ROTTLE -	Gas-Gasoline Only
	520A629	1	Spec L Only
	520A517	ŀ	Begin Spec M

- Order by description giving complete Model, Spec, and Serial Number.
- ** For components contact your nearest Impco dealer or Impco Division, 16916 Gridley Place, Cerritos, California 90701.









REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
ı	191D486	1	**Starter - 12-Volt (Delco Remy #1113167-H)
2	191P251	1	**Generator, 12-Volt - To Spec K (Delco Remy #1102044)
3	191A228	ŧ	Regulator, Voltage - Prior to Spec K
4	191A253	l	Fan, Generator Pulley - Spec A Models Only
5	511P25	ŀ	Belt, Generator
6	191A267	l	Eracket, Voltage Regulator Mounting - Prior to Spec K
7	312A58	2	Condenser - 0.1 Mfd (1) Charge Generator, (1) Voltage Regulator
8	337A49	2	Strap, Ground (Braided) - 8-7/16 Long
9	338B208	1	Harness Assembly, Charge Regulator - To Spec K
10	191C266	t	Pulley, Generator - Spec A Models Only
11	191C296	i	Fan and Pulley, Spec B through J
12	1918665	I	*Alternator, Charging (Includes Regulator) - Begin Spec K (Motorola #70D44039B)
13	191B649	l	Pulley, Alternator - Begin Spec K


- * For components contact your nearest Motorola dealer or Motorola Automotive Products Inc., 9401 W. Grand Ave., Franklin Park, Illinois 60131.
- ** For components contact your nearest Delco Remy dealer or Delco Remy Div. of General Motors Corp., Anderson, Indiana 46011.






REF.	PART NO.	QTY. USED	PART DESCRIPTION
1	403D555	1	Chassis, Mounting
2	405D I (53	i i	Panel, Front End
3	403C562	1	Trim, Chassis - RH Side
4	403C563	ŧ	Trim, Chassis - LH Side
5	405C1165	1	Hood, Radiator Extension
6	4 6 B 3 3 B	1	Frame, Battery Hold-down
7	416B358	I	Tray, Battery
· 8	520A231	2	Stud, Battery Hold-down
9	402A214	2	Bolt, Front Engine Mounting
10	402 P 209	2	Rubber, Generator End Mounting






NO.	NO.	USED	DESCRIPTION
I	403 D555	i	Chassis, Mounting
2	405D1153	1	Panel, Front
3	406A105	8	Clamp, Hold-down - Side Panels
4	403D556	1	Chassis, Mounting - Rear Section
5	405D1154	1	Panel, Rear - Excludes Door
6	405C1169	2	Support, Top
7	405D1155	2	Panel, Door - Housing Side - Includes Handles
8	405C1151	2	Panel, Side
9	405D1156	l l	Panel, Top
10	403 B566	1	Panel, Chassis
1.1	4168338	ı	Frame, Battery Hold-down
12	416B35B	ŧ	Tray, Battery
13	520A23 I	2	Stud, Battery Hold-down
14	405B932	1	Door, Rear Panel Control
15	406-2	1	Knob, Panel Door
16	406-88	1	Catch, Panel Door
17	402A214	ı	Bolt, Front Engine Mounting
18	402P209	2	Rubber, Generator End Mounting





REF.	PART NO.	QTY. USED	PART DESCRIPTION
ı	309P29	1	Thermostat
2	333A12	l l	Box, Thermostat
3	333A I3	ŧ	Cover, Thermostat Box
4	333P52	ı	Heater, Tank Type
5	503-183	l l	Clamp, Hose
6	503-131	3	Clamp, Hose
7	505-119	í	Elbow, Street (3/8" x 45°)
8	505-135	ŧ	Nipple, Half $(3/8 \times 1-1/2'')$
9	520A446	2	Stud, Thermostat Box Mtg.
10		1	Hose (Order 8" of Bulk Hose #503P386)
1.1		1	Hose (Order 11" of Bulk Hose #503P386)
12	505-19	1	Bushing, Reducer (1/2 x 3/8")
13	505-101	1	Nipple, Close (1/4″)
14	504-484	4	Tee, Pipe (1/4")
15	504-3	I	Valve, Drain
16	130A755	1	Bracket, Heater Support








NOTE: Output Terminal Box, Cover and Internal Parts are listed with the AC Output Control Group (Mounts on Side of Generator).

REF.	PART NO.	QTY. USED	PART DESCRIPTION
ł	•	1	Rotor Assy., Wound - Includes Bearing, Blower and Drive Assembly
2	205C49	i	Blower
3	510P63	į.	Bearing
4	•	1	Stator Assembly, Wound
5	212C24B	1	Rig Assembly, Brush - Includes Brushes & Springs
6	212B1105	4	Spring, Brush
7	214A56	4	Brush
8	150A717	(Switch Assembly, Overspeed
	COVER, E	ND BELL	OPENING - INCLUDES
	LATCH &	BRACKET	-
9	232B1254	2	Plain .
Ю	232B1253	2	Screened

a .	Order	hu	description,	aivina	Model	50.40	and	Serial
			ONAN Mame		1 10 401,	Jp CC	-,	

REF.	PART NO.	QT'	
11	234C84	1	Scroll, Air
12	312A17	I	Condenser - 0.5 Mfd.
. —	211E131	1	Bell, End - Alternator to Exciter
14	234C83	i	Band, Generator - Front Portion - Narrow
15	BAND, GEN	ERATOR	R - REAR PORTION - WIDE
	234D81	1	50KB Single Phase and 60KB Models
	234D82	\$	50KB 3 Phase Models
16	232A1186	1	Holder, Bearing - Anti-Rotation
17	232A1187	1	Spring, Bearing Holder - Anti-Rotation
18	232C1556	2	Pad, Generator Mounting
19	336 A 1082	ŧ	Lead, Overspeed Switch






REF.	PART	QTY.	PART	REF.	PART	QTY.	PART
NO.	NO.	USED	DESCRIPTION	NO.	NO.	USED	DESCRIPTION
I	COVER, E	XCITER		14	520A579	2	*Stud, Resistor and Rectifier
	234D59	1	Spec A Models Only		-		Mounting (NOTE: I only
_	234D106	1	Begin Spec B				included with #305B202 assy).
2	520A575	3	Stud, Exciter Cover Mounting	15	232A1473	2	*Spacer, Adjustable Resistor and
	866- i	3	Nut, Acorn - Exciter Cover Mounting				Rectifier to Stud (3/8" O.D. x 3/16" I.D. x 7/32" Long)
3	PANEL OF	NLY, EXC	ITER	16	304A14	2	*Washer, Centering - Adjustable
	234D100	i	Spec A Models Only				Resistor Mounting
	234D105	1	Begin Spec B	17	305-208	4	*Rectifier, Regulator (Control)
4	305B212	1	Rectifier Assembly, Power	18	315A57	2	Reactor, Gate
			(Complete) Includes four	19	234B62	2	Retainer, Gate Reactor
			#305-211 plus wire and howe.	20	232A1361	2	Stud, Gate Reactor Mounting
5	305-211	4	Rectifier Only, Power (Field) Included with #305B212 Assembly	21	304A21	ı	Resistor, Fixed - Alternator Field (Damping) 3/4" x 4" (200-Ohm, 50-Watt)
6	150B733	ŧ	Bracket Only, Overspeed Switch	22	304A15	2	Washer, Centering - Fixed
7	232A1365	i	Stud and Contact Point Assy.	**	207012	-	Resistor Mounting
•		•	Voltage Control Reactor	23	332A604		Block, Terminal - 5 Place
			Mounting	23	332A67B	i	Strip, Block Marker - For
8	WASHER.	FIBRE IN	SULATING - VOLTAGE CONTROL	47	3327-070	•	5 Place Block
	REACTOR				CONDENSE	R - 0.5 M	
	508-18	2	1/4" x 3/4" x 1/16"	25	312A17	1	Left Hand - Spec A Models
	508-29	1	1/4" x 3/8" x 1/32"	2.3	312/11/	•	Only
9			SE CONTROL - Does Not Include	26	312A27	1	Right Hand - Spec A Models
	Terminal B	llock					Önly
	315A49	l l	Spec A Model's Only		INSULATIO	N, REAC	TOR MOUNTING
	315A74	l l	Begin Spec B	27	232A1051	4	Gate Reactor to Mounting
10	BLOCK, T	ERMINAL	- VOLTAGE CONTROL REACTOR				Bracket (1-1/4" x 1-5/8" x
	332A622	t	Spec A Models Only				I/8 ")
	332A687	I	Begin Spec B	28	895-70	8	(6) Gate Reactor to Retainer,
1 1	305 B202	ı	Rectifier Assembly, Resistor and (Includes parts marked * plus wire and hardware).				(2) Voltage Control Reactor Mounting - SPECIFY SIZE REQUIRED
12	234B60	2	*Bracket, Gate Reactor Mounting (NOTE: I only included with #305B202 assembly).	29	232A1474	2	Spacer, Fixed Resistor to Stud (3/8"O.D. x 3/16"1.D. x 11/32" Long)
13	304A5	1	*Resistor, Control - Adjustable	30	332A537	1	Block, Terminal - 4 Place
_	·· ·•		(150-Ohm, 25-Watt) 9/16"×2"	31	332A686	1	Strip, Terminal Block Marker -

^{* -} Included in Resistor and Rectifier Assembly #305B202.

4 Place Block








REF.	PART	QTY.	PART !
NO.	NO.	USED	DESCRIPTION
1	PANEL ON	LY. LOW	ER CONTROL
	30101608	1	Prior to Spec F
	301C1916	1	Spec F and G
	301C2124	1	Begin Spec H
2	308 A 166		Switch and Adapter Assembly,
			Start-Stop - Prior to Spec F
2A	308P154	1	Switch, Start-Stop - Spec F
			through G
4	302A61	1	Ammeter, Charge (30-0-30)
5	193B106	ł	Gauge, Water Temperature
6	193B107	1	Gauge, Oil Pressure
7	307 A388	1	Relay, Time Delay
8		ASSEMBL	Y, WIRE - ENGINE TO CONTROL
	338C211	ı	Housed Models - Prior to Spec K
	338C416	ı	Housed Models - Begin Spec K
	338C209	ı	Unhoused Models - Prior to
	2200415		Spec K
^	33BC415	 	Unhoused Models - Begin Spec K
9	RELAY, E	TERGEN	
	307 B299 307 B6 14	!	Prior to Spec F
9A	307 A655	'	Spec F and G
74	30/ 4655	1	Relay, Latching - Emergency Stop - Begin Spec H
10	30B-91	1	Button, Emergency Stop Re-Set -
	300-71	1	Prior to Spec H
11	RELAY		
	307 B4	1	Stop - Prior to Spec H
	307 B4	ł	Anti-Dieseling Solenoid Start -
			Prior to Spec H
12	RELAY, ST	TART IGN	ITION
	307 B8 I	1	Prior to Spec H
	307 B597	I	Begin Spec H
13	307 B52	1	Relay, Start-Disconnect
14	RELAY, ST	CARTER I	
	307 B40	ı	Prior to Spec H
	307 B5 4		Begin Spec H
15	322-49	J	Receptacle, Panel Light - Housed
			Models Only - Prior to Spec H

REF.		QTY	
NO.	NO	USE	DESCRIPTION
15A	322P72	2	Receptacle, Panel Lights - Begin Spec H
16	BULB, PAN	IEL LIGH	•
	322-26	t	Prior to Spec H - Houses Models Only
	322-4	3	Begin Spec H (2) Panel Lights (1) Pilot Light
17	332A607	į	Block, Terminal - Engine
			Connections - 12 Place
	BLOCK, TI	ERMINAL	- REMOTE CONNECTION
18	332A537	1	4 Place - Prior to Spec H
IBA	332A611	ŧ	3 Place - Begin Spec H
19	332A608	1	Strip, Block Marker (Marked 4
			through 15)
	STRIP, BL	OCK MAR	KER - REMOTE CONNECTION
20	332A566	l	Prior to Spec H - (Marked B+, I, 2, 3)
20 A	332A762	I	Begin Spec H - (Marked Remote, B+, Ground)
21	304-45	ţ	Resistor, Fixed (4-Ohm, 50-Watt) - 3/4 x 4"
22	RESISTOR	FIXED -	5/16 x 1-3/4"
	304-32	1	15-Ohm, 10-Watt - Prior to Spec H
	304A192	1	3-Ohm, 10-Watt - Begin Spec H
23	301A1685	I	Bracket, Time Delay Relay Mounting
24	322P69	I	Receptable Assembly, Pilot Light - Begin Spec H
25	320A104	1	Breaker, Circuit - Cranking Limiter - Begin Spec H
26	308-2	1	Switch, Panel Lights - Begin Spec H
27	308P138	i .	Switch, Run-Stop-Remote - Begin Spec H
28	307 B597	1	Relay, Ignition - Begin Spec H
	306A211	ı	Bracket, Starter Pilot Relay - Begin Spec K








NOTE: For Unhoused Models with Optional Meter Panel, use Control Group as listed for Housed Models.

REF.	PART NO.	QTY. USED	PART DESCRIPTION
	BOX ONLY,	CONTR	OL
ŀ	301D1537	1	Prior to Spec H
IA	30 ID2 I I5	1	Begin Spec H
2	PANEL ON	Y, CON	
	301C1666	ŧ	All Models EXCEPT 480 Volt - Spec A Only
	301C1657	ŧ	480 Volt Model - Spec A Only
	301C1809	1	All Models Begin Spec B
4	BRACKET.	CONTRO	L BOX MOUNTING
	301C2539	ı	3-Phase Models (Replaces 2 Piece Bracket)
	301C1830	I	I-Phase Models (Models with Unity Power Factor Use 30 IC2539)
4A	508 P63	ľ	Grommet, Mounting Bracket
5	402-78	4	Rubber, Mounting - Control Box to Mounting Bracket
6	337 A44	1	Strap, Ground
7	VOLTMETE	R, AC	
	302P421	ı	120/240 Volt - Phase Models, and 120/208 Volt and 120/240 Volt - 3 Phase Models - (0-300)
	302P422	1	480 Volt, and 277/480 Volt - 3 Phase Models - (0-600)
	302P423	1	600 Volt - 3 Phase - (0-750)
8	302-157	1	Multiplier, Meter (Resistor) - 480 Volt Models Only - Prior to Spec H - (Used with
			0-500 Voltmeter)
9	320B170	f	Breaker, Circuit
	BLOCK, TE	RMINAL	
10	332A333	ľ	All Models EXCEPT 480 Volt- Spec A Only (2 Place Block)
11	332A391	ŀ	480 Volt Models - Spec A Only - (4 Place Block)
	STRIP, TER	MINAL E	BLOCK MARKER
12	332A600	1	All Models EXCEPT 480 Volt - Spec A Only - (2 Place)
13	332A427	1	480 Valt Models - Spec A Only -

(4 Place)

REF		QTY.	
14	BOX, OUTP	UT TERN	1INAL (Mts. on Side of Generator)
	301E1675	1	Single Phase Models - (NOTE:
			Models with Unity Power
			Factor use 301B1209)
	301B1209	1	All 3 Phase Models
15	COVER, OU	TPUT TO	ERMINAL BOX
	301B1676	1	Single Phase Models - (NOTE:
			Models with Unity Power
			Factor use 301B1190)
	301B1190	1	All 3 Phase Models
16	RHEOSTAT	, VOLTA	GE REGULATOR - 75-Ohm Model
	H - Begin Sp	ec B	
	303-111	1	Single Phase Models - (NOTE:
			Models with Unity Power
			Factor use 303-97)
	303- 9 7	1	All 3 Phase Models
17	303-32	1	Knob, Rheostat - Begin Spec B
18	RESISTOR,	RHEOST	AT - BEGIN SPEC B
	304 A484	1	Single Phase Models - (NOTE:
			Models with Unity Power
			Factor use 304A479) -
			825-Ohm - 75-Watt
	304A479	1	All 3 Phase Models -
			425-Ohm - 50-Watt
19	332A604	1	Block, Terminal (5 Place) -
			Begin Spec B
20		MINAL E	BLOCK MARKER
	332A689	I	120/208 Volt, 120/240 Volt,
			600 Volt - 3 Phase Models
	332A690	1	Single Phase Models, and 480
	. *		Volt, and 277/480 Volt -
			3 Phase Models - (NOTE:
			Single Phase Models with
			Unity Power Factor use
			332A689)
21	BACK PLAT		
	301B1714	ş	Spec B through G
	301B2222	1	Begin Spec H
22	30 A458	4	Spacer, Control Box Back
			Plate - Begin Spec B
23	301A1914	I	Bracket, Panel Stop





NOTE: Use this group also for Unhoused Models with Optional Meter Panel. (Standard on Housed Models).

REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF		QTY USE	
	BOX ONL	Y, CONTR	IOL .		302P467	1	277/480-Volt, and 480-Volt-
1	301D1537	!	Prior to Spec H	İ			3 Phase Models
IA			Begin Spec H	17		RUNNING	TIME METER
2	PANEL O	NEY, CON		1	304A444	1	Used on some early 120/240-Volt
	****		Spec A Models Only	i			Models - Prior to Spec H -
	30101641	1	50, 000-Watt - Single Phase	1			(Used with 302-387 Meter)
	301C1642	!	All 50, 000-Watt - 3 Phase	1	304A445	ı	Used on some early 480-Volt
	301C1658	1	60, 000-Watt - 3 Phase				Models - Prior to Spec H -
		_	Spec B through G				(Used with 302-387 Meter)
	301C1810	1	50, 000-Watt - Single Phase		304A125	ı	480-Volt, and 277/480-Volt -
	301C1814	1	120/208-Volt, and 120/240-				3 Phase Models - Prior to
			Volt - 3 Phase				Spec H - (Used with 302-212
	301C1824	ı	480-Volt, 277/480-Volt, and				Meter)
			600-Volt - 3 Phase		304A 34	1	600-Volt - 3 Phase Models -
			Begin Spec H				Prior to Spec H - (Used with
	301C1810	I	50, 000-Watt - Single Phase	i			302-212 Meter)
	301C1814	ļ	120/208-Volt, 120/240-Volt,		304A536	ţ	600-Volt - 3 Phase Models -
			277/480-Volt, 480-Volt,	1	30 1. 1300		Begin Spec H - (Used with
			and 600-Volt - 3 Phase	1			302P465 Meter)
3	301C2539	1	*Bracket, Control Box Mounting	18	301D1209	i	Box, Output-Terminal (Mts. on
•	55.5255		(Repl. 2 Piece Bracket)	'8	30101207	•	Side of Generator)
4	508 P 6 3	1	*Grommet, Mtg. Bracket	١,,	20101100	,	Cover, Output Terminal Box
5	402-78	4	*Rubber, Mounting - Control Box	19	301B1190	DMED CHB	RENT (Mts. Inside Terminal
Þ	702-76	7	to Mtg. Bracket	20	IKANSEU	KMEK, CON	er Nameplate - Select According
,	227 8 4 4		-			K Iranstorm	er Maniehrate - Serect Accounts
6 7	337A44	·	Strap, Ground		to Rating)	2	Transformer Nameplate Reads
′	VOLTMET		100/0/0/4	j	302 B76	3	"Ratio 75/5" - (Use with 0-75
	302P421	ł	120/240-Volt - Single Phase,				
			and 120/208-Volt, and 120/240-	1	202570	•	AC Ammeter) Transformer Nameplate Reads
	_		Volt - 3 Phase Models - (0-300)		302B78	3	
	302P422	ı	277/480-Volt, and 480-Volt -				"Ratio 100-5" - (Use with
			3 Phase Models - (0-600)	1		_	0-100 AC Ammeter)
	302P423	ţ	600-Volt - 3 Phase Models -	1	302B125	3	Transformer Nameplate Reads
			(0-750)				"Ratio 140/5" - (Use with
8	302-157	1	Multiplier, Meter (Resistor) 480-				0-140 AC Ammeter)
			Volt Models - Prior to Spec H -	1	302 B 106	3	Transformer Nameplate Reads
			(Used only with 0-500 Scale	İ			"Ratio 200/5" - (Use with
			Voltmeter)	1			0-200 AC Ammeter)
9	320B 170	1	Breaker, Circuit	1	302B209	3	Transformer Nameplate Reads
10	332A503	1	Block, Terminal (8 Place)	ì			"Ratio 250/5" - (Use with
11	332A601	į	Strip, Terminal Block Marker				0-250 AC Ammeter)
			(8 Place)		302B107	3	Transformer Nameplate Reads
12	332A333	1	Block, Terminal - 2 Place - 480-	1			"Ratio 300/5" - (Use with
	332.1333	•	Volt Plants - Spec A Only				0-300 AC Ammeter) - NOTE:
13	332A600	ı	Strip, Block Marker - 2 Place -				Quantity is 2 for Single Phase
()	3327000	'	480-Volt Plants - Spec A Only	ı			Models.
1.4	200 77	,		1	CLAMP	CHRRENT 3	TRANSFORMER MOUNTING
14	308-22	1	Switch, Voltage & Current Selector - 3 Phase Models Only	21	302A235	3	Inside Half (NOTE: Quantity is
1.5	A.A.45.T.C.O	AC (C)		1 -	302/1233	•	2 for Single Phase Models)
15			eck Ammeter Scale - Select	22	302A236	3	Outside Half (NOTE: Quantity
	According	to Kating			302/1230		is 2 for Single Phase Models)
	302P406	1	Ammeter Scale Reads 0-75		303.07	ſ	Rheostat, Voltage Regulator -
	302P408	ł	Ammeter Scale Reads 0-100	23	303-97	i.	75-Ohm, Model H - Begin
	302 P409	1	Ammeter Scale Reads 0-140				· —
	302P411	1	Ammeter Scale Reads 0-200				Spec B
	302P412	I	Ammeter Scale Reads 0-250	24	303-32	1	Knob, Rheostat - Begin Spec B
	302P413	ı	Ammeter Scale Reads 0-300	25	304A479	1	Resistor, Rheostat - Begin Spec
16	METER, R	UNNING "	TIME - 60 CYCLE PLANTS			_	B
	302-212	I	Prior to Spec H - (NOTE: When	26	332A604	i	Block, Terminal - 5 Place - Begin
			used to replace 302-387 on	i			Spec B
			plants requiring a resistor also	27	STRIP, B	LOCK MARI	KER - 5 Place
			order #304A99 Resistor for	i	332A689	ı	120/240-Volt - Single Phase, and
			120/240-Volt or #304A125 for				120/208-Volt, and 120/240-Volt
			480-Valt or #304A134 for 600-				- 3 Phase Models - Begin Spec B
			Volt Models)		332A690	1	480-Volt, 277/480-Volt, and 600-
			· ·		-		Volt - 3 Phase Models - Begin
	2020445		Begin Spec H				Spec B
	302P465	i	120/240-Volt - Single Phase,	28	*BACK PI	ATE, CONT	
			and 120/208-Volt, 120/240-	1 20	301C1714		Prior to Spec H
200	Derror		Volt, and 600-Volt-3 Phase	i	30 B2222		Begin Spec H
City.	Power		Models	•	3010222	•	Redistribution or publication of this docume

Current Generation

Begin Spec H
Redistribution or publication of this document
by any means, is strictly prohibited.
47

REF. NO.	PART NO.		TY. PART SED DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION
	301C458 301A1914	4	*Spacer, Control Box Back Plate Bracket, Panel Stop				
2.1	302 D440		Dideket, Laifel 3(0)				


^{* -} These parts used only on Unhoused Models WITH OPTIONAL Meter Panel.

Plate, Meter Face

3 |

302B448

CITY WATER COOLING SYSTEM GROUP- OPTIONAL		: See separ		for plants with water cooled nger.
	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
		503P364	2	Hose, Upper
	2	503P365	4	Clamp, Hose
	3	505-474	ı	Nipple, Half (1-1/2 × 5") - Unhoused Plants
	3	505-272	ı	Nipple, Ha!f (1-1/2 × 4") - Housed Plants
32 4	4	505-317	ł	Tee (1-1/2")
-\ \ \ 3	5	505-424	1	Nipple, Pipe (1-1/2 x 16-1/2")
	6	130B488	1	Support, Pipe
Jest Jakan 1	7	505-398	1	Tee, Side Outlet (I-1/2")
2	8	505-272	1	Nipple, Half (I-1/2 x 4") - Unhoused Plants
5/	8	505-385	ł	Nipple, Half (1-1/2 x 2") - Housed Plants
10	9	505-426	ı	Bushing, Reducer (1-1/2 x 1/4")
12	10	505-11	f	Elbow, Street (1/4") - 2 used on Housed plants
	П	505-10	2	Nipple, Half (1/4 x 1")
30 33	12	503-32	2	Clamp, Hose
	13		1	Hose (Order 20" of Bulk Hose #503P110)
27	14	505-20	ţ	Bushing, Reducer (3/4 x 1/4")
\ 28 7	15	505-166	2	Tee, Pipe (3/4")
	16	505-324	I	Nipple, Half (3/4 x 2")
	17	505-84	1	Nipple, Pipe (3/4 x 2-1/2") -
20				2 used on Housed plants
26 29	81	505-131	ŧ	Bushing, Reducer (3/4 × 3/8")
14/	19	504-28	l	Valve, Drain
23	20	505-102	2	Nipple, Close (3/4″)
5/16	21	130A452	1	Inlet, Water
22	22	503 P354	2	Clamp, Hose
21 - 12	23		ŀ	Hose (Order 3" of Bulk Hose #503-357)
71	24	503-189	2	Clamp, Hose
31 15 10	25		1	Hose (Order 34 " of Bulk Hose #503-249)
1	26	505-132	2	Elbow, Pipe (3/4" x 90°)
20	27	307 P835	ı	Solenoid Valve
25	28	110A810	1	Nipple & Bracket
	29	504-46	1	Valve, Lockshield
24	30	504-20	1	Key, Lockshield Valve
18	31	505-165	1	Nipple, Pipe (3/4 × 5-1/2")
	32	505-402	1	Plug, Pipe (I-I/2´´)
1 20	33	130A528	1	Support, Pipe
16		130C454	I	Guard, Belt, Unhoused plants only
		130B455	1	Bracket, Belt Guard - Unhoused plants only
		403C384	I	Extension, Radiator Hood - Unhoused plants only




NOTE: See separate groups for plants without heat exchanger and/or city water cooled manifolds.

REF.	PART NO.	QTY. USED	PART DESCRIPTION
I	155C656	t	Header Assy., Exhaust - Prior to Serial #39C090774
2	505-216	2	Elbow, Street (2-1/2")
3	MANIFOLD,	WATER	COOLED
	154P583	2	Prior to Serial #39C090774
	154P1245	2	Begin Serial #39C090774
4	154A611	4	Flange
5	145A178	4	Gasket, Flange
6	505-50	6	Elbow, Street (1/2"x 90°) -
			Manifold Water Inlet +
			Prior to Serial #39C090774
6A	505-40	5	Elbow, Pipe (1/2" x 90°) -
			Manifold Water Inlet -
			Begin Serial #39C090774
7	503-189	8	Clamp, Hose
8	HOSE		
		2	Order 5-1/2" of Bulk Hase
			#503P191 - Prior to
			Serial #39C090774
		2	Order 8" of Bulk Hose #503P191
			· - Begin Serial #39C090774
9	505-100	8	Nipple, Pipe (1/2 x 1-1/8") -
			NOTE: Prior to Serial
			#39C090774 Quantity of 3 each.
10	505-108	3	Tee, Pipe (1/2")
11	505-185	8	Nipple, Half (1/2 x 1-1/2")

REI NO		QTY. USED	
12	HOSE	ı	Order 10" of Bulk Hose #503P19 - Prior to Serial #39C090774
		ı	Order 13-1/2" of Bulk Hose #503P191 - Begin Serial #39C090774
13	HOSE	ı	Order 25-1/2" of Bulk Hose #503P191 - Prior to Serial #39C090774
		I	Order 30" of Bulk Hose #503P19 - Begin Serial #39C090774
14	155A661	2	Band, Exhaust Shield Mtg.
15	155A660	2	Bracket, Exhaust Shield Mtg.
16	155C659	2	Shield, Exhaust Header
17	130A745	1	Line, Water
18	148-274	1	Clamp, Hose Support
19	505-19	1	Bushing, Reducer (1/2 x 3/8")
20	504-28	1	Valve, Drain
21	504-5	2	Valve, Drain
22	TUBE, EXH	AUST - Be	egin Serial #39C090774
	15581048	1	Left Side
	15581047	ı	Right Side
23	505-373	ı	Tee, Reducing (2-1/2 x 2-1 2 x 3) - Begin Spec #39C090774
24	155A615	ı	Nipple, Half - Begin Serial #39C090774
25	505-57	2	Plug, Pipe (1/8)
26	505-248	ı	Elbow, Street (1/2 x 45°)
	154P592	2	Gasket Set. Manifold





NOTE: See separate groups for plants with heat exchanger and city water cooled without water cooled manifolds.


REF. NO.	PART NO.	QTY.	PART DESCRIPTION
!	VALVE.	SOLENOID	
	307P835	1	Prior to Serial #29C090774
	307PB33	1	Begin Serial #39C090774
2	NIPPLE	& BRACKET	•
	110A810	Ĺ	Prior to Serial #39C090774
	110A526	1	Begin Serial #39C090774
3	505-132	1	Elbow, Pipe (3/4" x 90°)
3A	ELBOW,	PIPE	-
	505-132	1	3/4 x 90 ° - Prior to Serial #39C090774
	505-40	1	1/2 x 90° - Begin Serial #39C090774
4	505-324	2	Nipple, Half (3/4" x 2")
5	503-189	8	Clamp, Hose
6	HOSE		
		1	Order 18" of Bulk Hose
			#503-249 - Prior to
			Serial #30C090774
		ł	Order 23" of Bulk Hose
			#503-386 - Begin
-			Serial #39C090774
7			INLET - MANIFOLD - Prior
		#39C090774	0
	154B595	2	Rear
	1548602 1548594	,	Right Front Left Front
8	503P364	2	Hose, Upper
-	503P365	4	Clamp, Hose
10	505-272	7	Nipple, Half (1-1/2 x 4")
11	505-398	i	Tee, Side Outlet (1-1/2")

RE!		QTY. USED	PART DESCRIPTION
12	505-474	1	Nipple, Half (I-1/2 x 5")
13	505-426	ĺ	Bushing, Reducer (1-1/2 x 1/4")
14	505-11	4	Elbow, Street (1/4")
15 16	505-10 HOSE	2	Nipple, Half (1/4")
		1	Order 34" of Bulk Hose #503-249 - Prior to Seria! #39C090774
		1	Order 38" of Bulk Hose #503-386 - Begin Serial #39C090774
17		1	Hose (Order 9" of Bulk Hose #503P110)
19	154A596	1	Cover, Flange - Prior to Serial #39C090774
20		1	Hose (Order 7 " of Bulk Hose #503-249)
20/	A HOSE		
		1	Order 7" of Bulk Hose #503-249 - Prior to Serial #39C090774
		1	Order II" of Bulk Hose #503-386 - Begin Serial #39C090774
21	505-166	2	Tee, Pipe (3/4")
22	505-131	Į.	Bushing, Reducer (3/4 x 3/8"
23	504-28	1	Valve, Drain
24	505-102	i	Nipple, Close (3/4")



REF.		QTY.	PART	REF.	PART	QTY.	PART
NO.	NO.	USED	DESCRIPTION	NO.	NO.	USED	DESCRIPTION
24A	NIPPLE, PI	PE		50	154A611	4	Flange, Water Inlet - Begin
	505-102	t	3/4"x Close - Prior to				Serial #39C090774
			Serial #39C090774	51	505-185	4	Nipple, Half (1/2 x 1-1/2") -
	505-100	l	1/2" x Close - Begin	1			Begin Serial #39C090774
3.5	1204 455		Serial #39C090774	52	504-40	4	Elbow, Pipe (1/2 x 90°) -
25	130A452		Inlet, Water	l		_	Begin Serial #39C090774
26		I	Hose (Order 3" of Bulk Hose #503-357)	53	505-100	4	Nipple, Pipe (1/2 x Close) - Begin Serial #39C090774
27	503P354	2	Clamp, Hose	54	505-21	1	Bushing, Reducer (3/4 x 1/2) -
28	505-216	2	Elbow, Street (2-1/2")	l			Begin Serial #39C090774
29	155C656	1	Header Assy., Exhaust - Prior	55	NIPPLE, H.	ALF	
			to Serial #39C090774	1	505-324	2	3/4 x 2" - Prior to Serial
30	155A661	2	Band, Exh. Shield Mtg.	1			#39C09077 <u>4</u>
3 1	MANIFOLD, 154P583	WATER (COOLED Prior to Serial #39C090774		505-185	2	1/2 x 3-1/2"- Begin Serial #39C090774
	154P1245	. 2	Begin Serial #39C090774	56	505-287	ŧ	Elbow, Street (3/4" × 45°) -
32	505-84	. 2	Nipple, Pipe (3/4 x 2-1/2")	1 5	303 107	•	L.H. Front Manifold Water
33	505-57	2	Plug, Pipe (1/8")	İ			Inlet - Housed Plants Only -
34	505-424	ī	Nipple, Pipe (1-1/2" x 16-1/2")	1			Prior to Serial #39C090774
35	505-317	i	Tee (1-1/2")	1	505 304	1	Nipple, Half (3/4 × 2 ") - L.H.
36	155C659	ż	Shield, Exh. Header	57	505-324	ı	Front Manifold Water Inlet -
37	155B660	2	Bracket, Exh. Shield Mtg.	1			Housed Plants Only -
39	145A178	4	Gasket, Flange	1			Prior to Serial #39C090774
39A	145A178	t	Gasket, Flange - Prior to	58	505-132	ı	Elbow, Pipe (3/4 x 90°) - L.H.
			Serial #39C090774	30	303-132	•	Front Manifold Water Inlet -
40	504-5	2	Valve, Drain	l l			Housed Plants Only -
41	130B4B8	ī	Support, Pipe			•	Prior to Serial #39C090774
42	503-32	2	Clamp, Hose		402 A I 37	2	Spacer, Coil Stud - Prior to
43	505-20	ī	Bushing, Reducer (3/4 x 1/4")				Serial #39C090774
44	VALVE, LO	CKSHIEL		1	520A458	2	Stud, Coil Mounting - Prior to
	504-46	Į	Prior to Serial #39C090774	ļ			Serial #39C090774
	504-19	1	Begin Serial #39C090774	1	520A44	16	Stud, Manifold Mounting
45	504-20	ŧ	Key, Lockshield Valve		154P592	2	Gasket Set, Manifold
46	505- 4 02	ł	Plug, Pipe (1-1/2")		130C454	1	Guard, Belt
47	TUBE, EXH	AUST - Be	egin Serial #39C090774	1	130B455	i i	Bracket, Belt Guard
	155B1048	F	Left Side		403C384	ı	Extension, Radiator Hood -
	155B1047	1	Right Side	İ			Unhoused Plants Only -
48	505-373	1	Tee, Reducer (2-1/2 \times 2-1/2 \times 3)				Prior to Serial #39C090774
			- Begin Serial #39C090774	1	305D1186	i	Top Panel, Hsg Housed
49	155A615	1	Nipple, Half - Begin Serial				Plants Only
			#39C090774		405D1185	ŧ	Door, Hsg Housed Plants Only






NOTE: Sée separate groups for city water cooling systems.

REF.	PART	QTY.	PART	NO.		QTY.	
NO.	NO.	USED	DESCRIPTION	10.	NO.	USED	DESCRIPTION
1	130A763	1	Bracket & Nipple	18	503B332	2	Hose, Upper
2	505-3	ŧ	Elbow (1-1/4")	19	130C454	l.	Guard, Belt
3	307-849	ı	Valve, Solenoid	20	130B751	1	Brace, Belt Guard
4	505-437	2	Nipple, Half (I-I/4 x 4")	21	505-385	3	Nipple, Half (1-1/2 x 2")
5	503-4	2	Clamp, Hose	22	505-317	1	Tee, Pipe (1-1/2")
6		I	Hose (Order 12" piece of Bulk Hose #503-359)	23	505-399	l	Bushing, Reducer (1-1/2" x 1/2")
7	505-138	1	Coupling, Reducer (1-1/4 x 1")	24	504-28	1	Valve, Drain
8	505-4	ļ	Nipple, Close (1 x 1-1/2")	25	505-19	ı	Bushing, Reducer (1/2 x 3/8")
9	50 5- 140	ŧ	Plug, Pipe (1")	26	503-365	2	Clamp, Hose
10	130 P753	1	Exchanger, Heat	27		1	Hose (Order 4" of Bulk Hose
11	503P354	4	Clamp, Hose				#503-411)
12		2	Hose (Order 4" piece of Bulk	28	505-41	I	Elbow, Pipe (1")
			Hose #503-357)	29	505-86	1	Nipple, Pipe $(1 \times 2 - 1/2^{\prime\prime})$
13	130A478	2	Inlet, Water	30	505-3	1	Elbow, Street (I-I/4")
14	505-95	1	Nipple, Pipe (1-1/2 x 12")	31	505-219	i	Nipple, Pipe (1-1/4 x 4-1/2")
15	505-43	ŀ	Elbow, Pipe (1-1/2")	į.	403C384	I	Cover, Chassis Front
16	130C752	1	Bracket, Heat Exchanger		504-51	1	Valve, Lockshield
17	503-311	2	Clamp, Hose		504-52	1	Key, Lockshield Valve





NOTE: See separate groups for city water cooling systems.

REF.	PART	QTY.	PART
NO.	NO.	USED	DESCRIPTION
1	130C475	1	Tank, Expansion
2	139P431	ł	Cap, Expansion Tank Fill
3	505-142	1	Nipple, Pipe (2 x 14")
4	505-42	1	Nipple, Pipe (2 x 8")
5	505-374	1	Tee, Pipe (2")
6,	505-168	· ·	Nipple, Pipe (2 x 2-1/2'')
7	130P416	1	Exchanger, Hear
8	BRACKET	, MTG.÷HE.	AT EXCHANGER, R.H.
	130B476	1	Unhoused Plants
	130B530	i	Housed Plants
9	BRACKET	', MTG. - HE	AT EXCHANGER, L.H.
	130B477	1	Unhoused Plants
	130B531	1	Housed Plants
10	505-187	1	Bushing, Reducer (2 x 1-1/2")
11	NIPPLE, I	PIPE	
	505-109	1	Unhoused Plants (1-1/2 x 2-1/21)
	505-109	2	Housed Plants (1-1/2 x 2-1/2")
	505-85	1	Unhoused Plants (I-I/2 x 2")
12	505-43	2	Elbow, Pipe (1-1/2" by 90°)
13	505-385	2	Nipple, HalfPipe $(1-1/2 \times 2'')$
14	503-287	2	Clamp, Hose
15		1	Hose (Order 3-1/2" of Bulk
			Hose #503-356)

REF.	PART NO.	QTY. USED	PART DESCRIPTION
16	505-317	ŀ	Tee, Pipe (1-1/2")
17	505-399	ļ	Bushing, Reducer (1-1/2 x 1/2")
18	505-19	1	Bushing, Reducer (1/2 x 3/8")
19	504-6	1	Valve, Shut-off - Drain
20	505-220	1	Nipple, Pipe (I-1/2 x 1-3/4")
21	130A478	1	Inlet, Water
22	503P354	2	Clamp, Hose
23	-	ł	Hose (Order 3" of Bulk Hose #503-357)
24	503-332	2	Hose, Expansion Tank
25	503-287	4	Clamp, Hose
26	130P493	I .	Flange, Union
27	130A486	2	Gasket, Flange to Exp. Tank
28	130C454	t	Guard, Belt - Unhoused Plants Only
29	130 B455	t	Bracket, Belt Guard - Unhoused Plants Only
30	520Å602	8	Stud, Heat Exchanger Flange Mtg.
	405D1285	1	Panel, Front End Hsg Housed Plants Only



SPECIAL PARTS SECTION

FOR KB SERIES PENNSYLVANIA APPROVED GENERATING PLANTS

Parts not listed in this section, refer to the standard, parts groups. Parts in this list are not illustrated.



GASOLINE FUEL SYSTEM & ANTI-DIESELING GROUP

PART NO.	QTY. USED	PART DESCRIPTION
307B284	t	Solenold & Lead Assy., Anti- Dieseling - Prior to Spec L
159C685	1	Line, Fuel Pump to Carburetor
415B161	1	Tank, Fuel (55-gal.) - Begin Spec J
415-43	i	Cap, Fuel Tank Fill - Begin Spec J
415-44	l	Cap, Fuel Tank Vent - Begin
415K7	2	Line, Fuel (25-ft.) - Begin Spec J
415A140	ŀ	Tube, Fuel Tank Suction - Begin Spec J
505-7	2	Bushing, 1/4 x 1/8" (Fuel Tank) - Begin Spec J
505-18	3	Bushing, 1/2 x 1/4" (Fuel Tank) - Begin Spec J
505-56	2	Plug, 1/2" (Fuel Tank) - Begin Spec J
505-211	ŧ	Pipe, Fuel Tank Fill (2 x 30") - Begin Spec J
505-212	1	Pipe, Fuel Tank Vent (I-1/4 x 36") - Begin Spec J
307P567	1	Valve, Solenoid - Reservoir Tank (36-Volt) - Spec J through K

IGNITION GROUP

PART NO.	QTY. USED	PART DESCRIPTION
COIL, IGN	HTION	
166P184	l	Prior to Spec J (24-Volt)
166 B278	1	Spec J through K (12-Volt)
416A37	2	Cable, Battery - Prior to Spec L
416A133	5	Cable, Battery - Jumper - Prior to Spec L
416P325	1	Hydrometer

STARTING MOTOR & BATTERY CHARGE GENERATOR GROUP - Prior to Spec L

PART	QTY.	PART
NO.	USED	DESCRIPTION
191B208	1	Cover, Starter Mounting Hole

GENERATOR GROUP (ALTERNATOR PORTION) Prior to Spec L

PART	QTY.	PART
NO.	USED	DESCRIPTION
2120194	1	Rig Assy., Brush
214A46	F	Brush
211E96	J	Beil, End - Alternator to Exciter
2328 253	3	Cover, End Bell Opening (Screened)

GENERATOR GROUP (ROTATING EXCITER PORTION) Prior to Spec L

PART NO.	QTY. USED	PART DESCRIPTION
•	1	Armature Assy,
•	ŀ	Frame Only
21201143	1	Holder, Brush Rig
•	4	Pole Shoe
•	1	Coil Assy. (Set of 4 Coils)
515-130	ı	Key, Exciter to Alternator Armature
212C2+1	†	Rig Assy., Brush
21281011	4	Spring, Brush
214A18	4	Brush
211C92	1	Cover, Exciter
336A629	2	Jumper, Brush Rig
232A1205	!	Washer, Centering - Armature Through Screw
232A1421	As Req.	Washer, Shim - Exciter to Alternator Armature

Order by description, giving complete ONAN Model, Spec, and Serial Number.

AUTOMATIC VOLTAGE REGULATOR GROUP Prior to Spec L

PART NO.	QTY. USED	PART DESCRIPTION
305P117	ŧ	Regulator, Voltage
305C163	.1	Base Assembly, Voltage Regulator
312A58	1	Condenser, . I Mfd.

CONTROL GROUP (ENGINE INSTRUMENTS PORTION)

PART NO.	QTY. USED	PART DESCRIPTION
193-3	1	Gauge, Oil Pressure - Prior to Spec L
193-8	i	Gauge, Water Temperature - Prior to Spec L
PANEL ON	LY, LOWE	R CONTROL
301C1316	1	Prior to Spec J
301C2428	1	Spec J through K
307 B234	1	Solenoid Start - Prior to Spec L
307 A 272	I	Bracket, Start Solenoid - Prior to Spec L
RESISTOR		
304A222	1	15-Ohm, 50-Watt - Adjustable - Spec J through K
304A62	1	25-Ohm, 25-Watt - Prior to Spec J
304A283	I	35-Ohm, 25-Watt - Prior to Spec L
304A37	ŀ	6-Ohm, 75-Watt - Prior to Spec J
304A32	ı	15-Ohm, 10-Watt - Prior to Spec L
304A11	t	50-Ohm, 25-Watt - Prior to Spec J
304A19	1	3-Ohm, 50-Watt - Prior to Spec L
304 A 58	ŧ .	50-Ohm, 50-Watt - Prior to Spec L
304 A46	1	10-Ohm, 50-Watt - Prior to Spec L



RELAY, K	SNITION	
306 A I 4 I	1	Prior to Spec J
306 A I 39	I	Spec J through K
307 P8 +9	l l	Begin Spec L
308-26	t	Switch, Start-Stop - Prior to Spec J
308P138	1	Switch, Run-Stop - Spec J through K
308 A 67	1	Guard, Switch - Prior to Spec J
323-52	1	Socket, Ignition Relay - Begin
		Spec L
332P943	2	Spacer, Ignition Relay Socket -
		Begin Spec L
307 P 778	F	Spring, Ignition Relay Hold Down -
		Begin Spec L

CONTROL GROUP (AC OUTPUT PORTION) UNHOUSED MODELS

NOTE: Unhoused models with OPTIONAL Meter Panel use Control Group listed for housed models.

PART NO.	QTY. USED	PART DESCRIPTION
301C1317	l	Panel Only, Control - Upper -
•	ı	Prior to Spec L Box Only, Control
303-65	ľ	Rheostat, Voltage Regulator -
203-03	,	Prior to Spec L
303P32	2	Knob, Rheostat - Prior to Spec L
303P90	1	Rheostat & Switch, Volt
		Regulator - Prior to Spec L
		RT DISCONNECT RELAY -
Prior to S	pec L	
304A131	ŀ	120/240-V, I-Ph., 120/208-V.
		3-Ph., and 120/240-V, 3-Ph.
		Models (750-Ohm, 25-Watt)
304A563	i	277/480-V, 3-Ph. Models
		(2500-Ohm, 25-Watt)
RELAY, 9	START DISC	ONNECT - Prior to Spec L
307 C664	ţ	120/240-V, 1-Ph., 120/208-V,
		3-Ph., and 120/240-V,
		3-Ph. Models
307C707	ı	277/480-V, 3-Ph. Models
BLOCK,	TERMINAL -	Prior to Spec L
332A333	ŧ	2-Place, I-Ph. Models
332A406	I	3-Place, 3-Ph. Models
STRIP, B	LOCK MARK	ER - Prior to Spec L
332A600	1	2-Place (23, 24), I-Ph. Models
332A426	1	3-Place (18,19,20), 3-Ph
		Modefs
308A12	1	Switch, Volt Selector - 3-Ph.
		Models - Prior to Spec L
303-76	ŧ	Knob, Volt Selector Switch -
		3-Ph. Models - Prior to
		Spec L
315B20	1	Transformer, 277/480-V, 3-Ph.
		Models - Prior to Spec L
320P307	1	Lock, Circuit Breaker Handle
		- Begin Spec L
301A2727	1	Handle, Control Panel - Begin
		Spec L

^{* -} Order by description giving complete Model, Spec. and Serial Number.

CONTROL GROUP (AC OUTPUT PORTION) HOUSED MODELS

NOTE: Use this group also for Unhoused Models with OPTIONAL METER PANEL.

PART NO.	QTY. USED	PART DESCRIPTION
PANEL O	NLY, CONT	FROL - Prior to Spec L
301C1356	1	I-Ph. Models
301C1374	ţ	3-Ph. Models
•	1	Box Only, Control
303-65	1	Rheostat, Voltage
		Regulator - Prior
		to Spec L
303 P 3 2	2	Knob, Rheostat - Prior
		to Spec L
303P90	1	Rheostat and Switch,
		Volt Regulator -
		Prior to Spec L
RESISTOR	R, OFF-STA	RT DISCONNECT RELAY -
Prior to Sp	oec L	
304A131	1	120/240-V, I-Ph., 120/208-V,
		3-Ph. and 120/240-V.
		3-Ph. Models (750-Ohm,
	_	25-Watt)
304A563	ı	277/480-V, 3-Ph. Models
		(2500-Ohms, 25-Watt)
	TART DISC	ONNECT - Prior to Spec L
307 C664	ı	120/240-V, 1-Ph., 120/208-V.
		3-Ph. and 120/240-V,
2076707	,	3-Ph. Models
307C707	!	277/480-V, 3-Ph. Models
315820	1	Transformer, 277/480-V,
1000007	1	3-Ph Prior to Spec L Lock, Circuit Breaker
320P307	•	
301A2727	ŧ	Handle - Begin Spec L Handle, Control Panel -
30 1 MZ/ Z/	1	Begin Spec L
		negiu spec r

Order by description giving complete Model, Spec, and Serial Number.

CITY WATER COOLING SYSTEM GROUP (PLANTS WITHOUT WATER COOLED EXHAUST MANIFOLDS OR HEAT EXCHANGER) - OPTIONAL EQUIPMENT - Prior to Spec L

PART	QTY.	PART
NO.	USED	DESCRIPTION
505-272	ŀ	Nipple, Half (1-1/2 x 4")
505-385	1	Nipple, Half (1-1/2 x 2")
307 P639	1	Valve, Solenoid

